

Smooth Hold Eyeliner Gel Pencil

Makeup | FM-MK-2025006

Features

Glides on smoothly in one stroke, sets instantly to lock in color. Offering a long-lasting, natural look that's smudge- and transfer-resistant.

Ingredients

● Synfumei® Synthetic Wax 6602, ☼ Cerafumei® Sunflower Wax 5301 and ● Microfumei® Microcrystalline Wax 6302 act as structurants, thickeners and plasticizers to provide desired texture, consistency and pay-off properties.

Phase	Ingredients	INCI	% wt	Function
A	RH-C229 ¹	Methyl Trimethicone	22.00	Solvent
	Isopar™ L ²	Isododecane	3.90	Solvent
	Bentone® 38V CG ³	Disteardimonium Hectorite	1.00	Thickener
	Alcohol ⁴	Alcohol	0.50	Solvent
	BELSIL® TMS 803 ⁵	Trimethylsiloxysilicate	15.00	Film former
	KF-56A ⁶	Diphenylsiloxy Phenyl Trimethicone	6.00	Skin conditioner
	Applecure PDS 300 ⁷	Polyhydroxystearic Acid (and) Caprylic/Capric Triglyceride (and) Isostearic Acid (and) Lecithin (and) Polyglyceryl-3 Polyricinoleate	1.00	Dispersant
	Synfumei® Synthetic Wax 6602 ⁸	Synthetic Wax	23.00	Structuring agent
	Cerafumei® Sunflower Wax 5301 ⁸	Helianthus Annuus (Sunflower) Seed Wax	4.00	Structuring agent
	Microfumei® Microcrystalline Wax 6302 ⁸	Microcrystalline Wax	2.00	Structuring agent
	DL-alpha-Tocopherol ⁹	Tocopherol	0.30	Antioxidant
	euxyl® PE 9010 ¹⁰	Phenoxyethanol (and) Ethylhexylglycerin	0.30	Preservative
B	BN-10 ¹¹	Boron Nitride	2.00	Skin conditioner
	Silica Bead SB-300 ¹²	Silica	2.00	Skin conditioner
	KTLEAD BLACK O-2 ¹³	CI 77499 (and) Triethoxycaprylsilane	17.00	Colorant

Suppliers: 1: Runhe 2: Exxonmobil 3: Elementis 4: Sinopharm 5: Wacker 6: Shin-Etsu Silicones 7: Applechem 8: Fumei 9: DSM 10: Schuelke 11: WISECKO 12: Miyoshi 13: KTFC

Procedure:

- Add ingredients 1, 2, 3 and 4 of phase A into the reactor, homogenize for 2 min until dispersed completely, add the remaining ingredients of phase A, and heat to 80-85°C until completely melted.
- Add ingredients 13, 14 and 15 of phase B and homogenize for 3 min. Stir and cool down to room temperature.

Specification:

Appearance: Gel texture
 Break-off value: 41 g (test equipment: CT3 texture analyzer, test condition: probe: TA7, target value: 3 mm, contact load: 2.5 g, test speed: 1.0 mm/s.)

Stability:

Pass 1 month at -18°C, 5°C, 25°C, 30°C, 45°C and 50°C.
 Freeze-Thaw test: 3 cycles.



Disclaimer:

The information in this publication is believed to be accurate and is given in good faith, but no representation or warranty as to its completeness or accuracy is made. Suggestions for uses or applications are only opinions. Users are responsible for determining the suitability of these products for their own particular purpose. NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE MADE REGARDING PRODUCTS DESCRIBED OR DESIGNS, OR THAT DATA OR INFORMATION MAY BE USED WITHOUT INFRINGING THE INTELLECTUAL PROPERTY RIGHTS OF OTHERS. Nothing contained herein is to be considered as permission, recommendation, nor as an inducement to practice any patented invention without the permission of the patent owner.